PowerBook G4 Aluminum 12" 1-1.5 GHz Airport Extreme Card Replacement

Written By: iRobot

This document was generated on 2020-11-19 06:51:50 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

INTRODUCTION

Install an Airport Extreme 802.11g card internally.

TOOLS:

- Coin (1)
- Spudger (1)

PARTS:

- Airport Extreme Card (1)
- G4 Aluminum 12" Airport Card Spacer (1)

This document was generated on 2020-11-19 06:51:50 PM (MST).

Step 1 — Battery

- Use a coin to turn the battery locking screw 90 degrees to the right.

- Lift the battery out of the computer.

Step 2 — Airport Extreme Card

- Flip down the door on the right side of the battery compartment.

This document was generated on 2020-11-19 06:51:50 PM (MST).

Step 3

- Use a spudger or flathead screwdriver to disconnect the Airport antenna from the card.

Step 4

- Grasp the plastic tab and pull the card out all the way.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-19 06:51:50 PM (MST).