



# iPhone 6 iSclack Opening Procedure

Prereq for display assembly.

Written By: Walter Galan



---

## INTRODUCTION

Prereq for display assembly.

---

### TOOLS:

- [iSclack](#) (1)
-

## Step 1 — iSclack Opening Procedure



- i** The next three steps demonstrate using the iSclack, a great tool for safely opening the iPhone 6 that we recommend for anyone doing more than one repair. **If you aren't using the iSclack, skip down three steps for an alternate method.**
- If the plastic depth gauge is attached at the center of the iSclack, remove it now—it's not needed for larger phones like the iPhone 6.
  - Close the handle on the iSclack, opening the suction-cup jaws.

## Step 2



- Place the bottom of your iPhone in between the suction cups.
  - Position the iSclack's upper suction cup against the display, just above (but not covering) the home button.
- Open the handles to close the jaws of the iSclack. Center the suction cups and press them firmly onto the top and bottom of the iPhone.

### Step 3



- Hold onto your iPhone securely and close the handle of the iSclack to separate the suction cups, pulling the front panel up from the rear case.
- The iSclack is designed to safely open your iPhone just enough to separate the pieces, but not enough to damage the display cables.
- Peel the two suction cups off your iPhone.
- **Skip the next three steps and continue on to Step 8.**

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-25 03:08:52 AM.