



MacBook Pro 13" Unibody Mid 2012 Feet Replacement

Replace the feet on a Mid 2012 MacBook Pro.

Written By: Adam O'Camb



INTRODUCTION

Bring an aging MacBook back to life with a new set of feet.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Tweezers](#) (1)
- [Isopropyl Alcohol Wipes](#) (1)
- [Adhesive Remover Kit](#) (1)

PARTS:

- [MacBook and MacBook Pro Unibody Plastic Feet](#) (1)
-

Step 1 — Lower Case




- Remove the following ten screws:
 - Three 14.4 mm Phillips #00 screws
 - Three 3.5 mm Phillips #00 screws
 - Four 3.5 mm shouldered Phillips #00 screws
- ⓘ When replacing the small screws, align them perpendicular to the slight curvature of the case (they don't go straight down).

Step 2



- Use your fingers to pry the lower case away from the body of the MacBook near the vent.
- Remove the lower case.

Step 3 — Feet



- Remove any broken or damaged feet.
- Remove any pieces from the old foot that may have broken off in the foot hole.
- Use tweezers to peel up and remove the old adhesive tape from the foot pad.

Step 4




- Scrub the foot pad with adhesive remover to remove any remaining adhesive.

Step 5



- Wipe the foot pad with an alcohol prep pad to remove any residue left by the cleaner.

Step 6



- Peel a replacement foot from the plastic backing.

Step 7



- Align the new foot inside the foot pad.
- Make sure the alignment nub on the foot is lined up with the small hole near the perimeter of the pad.
- Lay the foot down while keeping it properly aligned.
- Check for proper alignment from the inside of the lower case. Use tweezers to slide the alignment nub so it lines up with the hole.

Step 8



- Press the new foot down firmly with your finger and maintain pressure for 30 seconds to set the pressure sensitive adhesive.
- Repeat the last six steps for any broken or damaged feet.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-12-12 04:01:37 PM.