



Oil Change

This guide will cover the removal and replacement of old engine oil.

Written By: Jack Linchey



INTRODUCTION

Oil is what keeps an engine running smoothly and efficiently. Over time, the oil becomes viscous and dirty, and must be replaced to avoid harming the engine. Before starting this guide, ensure that you have an oil-safe catch tray.

TOOLS:


- [Latex or nitrile gloves](#) (1)
- [Oil Drain Pan](#) (1)
- [Paper Towels](#) (1)


PARTS:

- [Briggs & Stratton SAE 30W Engine Oil](#) (1)

Step 1 — Oil Change



 Make sure the engine is cool before completing the Oil Change.

- Rotate Dipstick Cap counterclockwise until completely unthreaded.
-  The Dipstick Cap is generally yellow or orange.

Step 2



- Place your Drain Pan below the engine and flip the engine over so that the used oil pours out of the Dipstick spout.
- Set the engine back down and fill the engine with the new oil until it reaches the designated fill line.

To reassemble your device, follow Step 1 and 2 in reverse order.

This document was last generated on 2019-07-21 01:01:46 PM.