



2006-2011 Honda Civic Key FOB Battery Replacement

Use this guide to replace the battery in an 8th-generation (2006-2011) Honda Civic Key fob.

Written By: Erika Caushi



INTRODUCTION

In this guide, we will replace the battery of a 2006-2011 Honda Civic key FOB. This is a fairly simple project that can be completed rather than potentially spending a minimum of \$90 on a replacement.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)

PARTS:

- [CR1616 Lithium Battery](#) (1)

Step 1 — Key FOB Battery




- Using the Phillips #0 screwdriver, remove the single screw from the bottom of the key FOB.

Step 2




- Gently lift the outer shell and remove it from the rest of the device.
- ⚠ Be careful not to break the clip located at the hole for the key ring that holds the shell in place.

Step 3




- Remove the inner shell from the outer shell by pushing the buttons to loosen the inner shell.

Step 4




- Unclasp the inner shell using the clips on the top and bottom.
- ⚠ Careful as to not break the clips as it keeps moisture, dust, and dirt from entering the delicate electronics.

Step 5



- Remove the battery inside of the inner shell of the key FOB.
- ⚠ If the battery is corroded, make sure to wear gloves due to battery acid.
- ⚠ Do not puncture the battery when removing the old one/placing a new one.

Step 6



- Replace the old battery with a new one.

To reassemble your key FOB, follow these instructions in reverse order.