



HTC One Max Fingerprint Sensor Replacement

Use this guide to replace a faulty fingerprint sensor.

Written By: Andrey Sklyar



INTRODUCTION

In this guide you are going to learn how to replace the fingerprint sensor on the HTC One Max phone.



TOOLS:

- [Spudger](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Tri-point Y00 Screwdriver Bit](#) (1)



PARTS:


- [HTC One Max finger print sensor](#) (1)
-

Step 1 — Back Case



- Lift back cover while pressing highlighted release switch towards the center of the phone.

Step 2




- Remove the four white stickers in each corner that cover the Tri-Wing screws.
- Remove the white sticker near the buttons that control the volume.
- Remove the white sticker near the SIM card.
- Remove the big white sticker with the bar-code in the center of the phone.

Step 3





- Remove the thirteen Tri-Wing Y00 screws (Upper & Lower screws are 5 mm length, middle screws are 3.8 mm length) from the back case.
- Disconnect the cable near the volume buttons.

Step 4



- Use the small plastic opening tool to pry between the screen and the rear case.

Step 5 — Fingerprint Sensor



- Use Tweezers to disconnect the ribbon cable connecting the fingerprint sensor to the motherboard.
- When replacing the fingerprint sensor, make sure the ribbon cable snaps into the port on the motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-04-06 11:39:04 AM.