



How to reset Cisco 7940 / 7960 IP phone to factory defaults

This work instruction will guide you through the steps to reset your IP phone to factory Defaults.

Written By: Goulithum

Step 1 — How to reset Cisco 7940 / 7960 IP phone to factory defaults



- In order to perform a factory reset of a phone if the password is set, complete these steps: 1. Unplug the power cable from the phone, and then plug in the cable again. The phone begins its power up cycle.

Step 2



- 2. Immediately press and hold # and while the Headset, Mute, and Speaker buttons begin to flash in sequence, release #. The Headset, Mute, and Speaker buttons flash in sequence in order to indicate that the phone waits for you to enter the key sequence for the reset.

Step 3



- 3. Press 123456789*0# within 60 seconds after the Headset, Mute, and Speaker buttons begin to flash. If you repeat a key within the sequence, for example, if you press 1223456789*0#, the sequence is still accepted and the phone resets.
- If you do not complete this key sequence or do not press any keys, after 60 seconds, the Headset, Mute, and Speaker buttons no longer flash, and the phone continues with its normal startup process. The phone does not reset. If you enter an invalid key sequence, the buttons no longer flash, and the phone continues with its normal startup process.
- If you enter this key sequence correctly, the phone displays this prompt: Keep network cfg? 1 = yes
2 = no
- In order to reset the network configuration settings when the phone resets, press 2.