



Axess SPBT1031 Red Interface Plate Replacement

Prerequisite Only This guide is for the removal of the red interface plate on the Axess SPBT1031.

Written By: Michael Bradley



 **TOOLS:**

- [Metal Spudger](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Red Interface Plate




- Use metal spudger to remove the mesh speaker covers (the side with the buttons) by wedging the narrow end into the center of the outer edge of the mesh, touching the red plate.

Step 2



- Use Phillips head PH1 to remove the four 5mm Phillips Head screws from the red panel (under mesh).

Step 3



- If the screws are difficult to remove, use a pair of tweezers to twist and pick them out.

Step 4



- Separate the red interface plate from the black face plate by pulling them apart.

To reassemble your device, follow these instructions in reverse order.