



# Basis Peak Band Replacement

This guide will explain how to replace the band of your Basis Peak fitness and sleep tracker.

Written By: Alexander Halliwell



---

## INTRODUCTION


The bands of the Basis Peak allow for several size adjustments for a snug fit to the user's wrist. A properly adjusted band is crucial to the functioning of the sensor on the underside of the watch. If the band is damaged or visibly tarnished, users can easily replace it with this guide. Two spring latches on the underside of the band halves must be released and the band halves will come right off.

---

### TOOLS:


- [Heavy-Duty Spudger](#) (1)

## Step 1 — Band



- Flip the watch over to view the back panel and sensor. Arrange the watch so that the band clasp is away from you.
- ⓘ Keep the watch in this position to help you follow the rest of the guide.

## Step 2



- Release the spring latches on the underside of each band to remove the bands from the frame.

To reattach the bands, follow these instructions in reverse order.