



iMac Intel 24" EMC 2134 and 2211 RAM Replacement

Replace the RAM in your iMac Intel 24" EMC 2134 and 2111.

Written By: Brittany McCrigler



INTRODUCTION

Upgrade your RAM for an instant increase in speed.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Spudger](#) (1)



PARTS:

- [iMac Intel 24" EMC 2134 \(Late 2007\) Memory Maxxer RAM Upgrade Kit](#) (1)
- [iMac Intel 24" EMC 2211 \(Early 2008\) Memory Maxxer RAM Upgrade Kit](#) (1)
- [PC2-5300 1 GB RAM Chip](#) (1)
- [PC2-5300 2 GB RAM Chip](#) (1)

Step 1 — Access Door



- Loosen the single Phillips screw in the center of the access door.
- ⓘ This screw is captive in the access door.
- Remove the access door from your iMac.

Step 2 — RAM



- Use the tip of a spudger to pull the black plastic RAM tabs out of the memory bay.
- Pull the black plastic RAM tab away from your iMac to eject the RAM module.

Step 3



- Grab the RAM module by its edges and pull it straight out of its slot.
- ⓘ If two RAM modules are installed, repeat this process for the other chip.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-11 05:39:42 AM.