



# PowerBook G4 Titanium DVI Hard Drive Replacement

Written By: iRobot



## INTRODUCTION

How to remove the hard drive, along with its cable and bracket from your computer.



### TOOLS:

- [T8 Torx Screwdriver](#) (1)



### PARTS:


- [iPod Touch Gen 1 Screw Set](#) (1)

## Step 1 — Battery



- Locate the battery release tab on the underside of the G4.
- Slide the battery release tab to the left and lift the battery out of the computer.

## Step 2 — Lower Case




- Remove the seven T8 Torx screws from the lower case.
- Using your thumbs, slide the lower case toward the front of the computer.
- The lower case may stick in the front on a tab just above the center of the optical drive. Be careful as you work the case off, or you may break the thin strip of plastic just above the drive.
- Lift the lower case off.

### Step 3 — Hard Drive



- Disconnect the hard drive ribbon from the logic board using a spudger or the tip of your finger.

### Step 4



- To free the hard drive, remove the two T8 Torx screws from the right wall of the battery housing.

## Step 5



- Remove the hard drive by lifting the left edge up and out of the computer.
- ⓘ There are four rubber bumpers that fit over the hard drive screws. Ensure that these bumpers come out when you remove the hard drive.

## Step 6



- Your laptop should look approximately like this.

To reassemble your device, follow these instructions in reverse order.