



Television Blaupunkt LCD-TV BW39B68BFBKUE480 Rocker Switch Kipp Netzschalter RS601D Replacement

Replacement for tilt switch LECI RS601D (alternatives / replacement) - eg. B. Marquardt
1858.1103

Written By: dieter



TOOLS:

- [Kreuzschlitzschraubendreher PH 2](#) (1)
- [Large Needle Nose Pliers](#) (1)



PARTS:

- [New Item](#) (1)

Step 1 — Blaupunkt LCD-TV BW39B68BFBKUE480 Rocker Switch Kipp Netzschalter RS601D



- The removal of the power switch is quite simple. First, open the case by removing all the screws on the rear panel marked with an arrow. (ATTENTION: different lengths and thickness! - when unscrewing remember which screw belongs where.

Step 2



- Then carefully lift off the back panel. Disconnect cables that prevent the rear panel from lifting off. Now, use a pair of needle nose pliers to squeeze the retaining clips that hold the switch in the TV housing and unclip the switch from the TV housing. (if necessary, use a flat screwdriver)

Step 3



- You should have some electrotechnical knowledge so that you will be able to correctly position the connectors on the new switch will . Now just clip on the switch. Plug in the disconnected cables. Fit rear panel and screw in all screws again.

Step 4



- Names from the original switch: LECI RS601D more details 6 (4) A250VAC new line: 10A 125VAC - other side: 6A250VAC new line: 6A / 125A250VAC - My problem was that the power switch was broken and the TV could only be switched on sporadically.

Step 5



- On Ebay, the switch RS601D (as of June 2017), is available as an original from China. An alternative: Since I just had it on hand, I installed the following switch from Pollin: # 420427 (unfortunately, no indication of inrush current found)

Step 6



- Probably also suitable: Marquardt 1858.1103 rocker switch, black, plug-in 4.8 mm, 10 (4.0) A / 250 VAC, 6.0 (4.0) A / 250 VAC e.g. from Bürklin: # 11 G 2854 - € 1.94

As already mentioned - connect the cable to the new switch and snap the snap-in switch back into the housing. Replace the back panel and screw in the screws again where they were screwed out.