



2009-2015 Toyota Prius Rear Brake Pad and Rotor Replacement

A video tutorial on how to change the rear brake pads and rotor on a 2009-2015 Toyota Prius.

Written By: eCuration



INTRODUCTION

If you are experiencing poor braking performance and or a noise when braking, then it may be time to replace the rear brake pads and or rotor.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.

Depending on the Toyota Dealership Parts & Service Department; 3M Silicone Paste, 3M Copper Anti-Seize, Sil-Glyde or the Toyota caliper guide pin and anti-seize/squeal grease are recommended respectively.

Torque specs:

- 26 ft. lbs - Caliper sliding pin bolts
- 42 ft. lbs - Caliper bracket bolts
- 76 ft. lbs - Wheel lug nuts

Safety

If this is your first time working on a vehicle read our [safety tips](#) before proceeding.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Wheel Chocks](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [14mm socket](#) (1)
- [14mm Wrench](#) (1)
- [Drive Disc Brake Piston Tool](#) (1)
- [Anti-Seize Lubricant](#) (1)
- [Torque Wrench](#) (1)
- [17mm Bike Wrench](#) (1)
- [Sil-Glyde Lubricant](#) (1)
- [21mm Socket](#) (1)



PARTS:

- [Rear Brake Pads](#) (1)
- [Brake Rotor](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-11 03:08:59 AM.