



iMac Intel 20" EMC 2133 and 2210 RAM Replacement

Written By: Walter Galan



INTRODUCTION

Upgrade your RAM for an instant increase in speed.

EMC 2133 models use PC2-5300 RAM and EMC 2210 models use PC2-6400 RAM. The maximum RAM for both models is 6 GB.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Spudger](#) (1)

PARTS:

- [iMac Intel 20" EMC 2133 \(late 2007\) Memory Maxxer RAM Upgrade Kit](#) (1)
- [iMac Intel 20" EMC 2210 \(Early 2008\) Memory Maxxer RAM Upgrade Kit](#) (1)
- [PC2-5300 1 GB RAM Chip](#) (1)
- [PC2-5300 2 GB RAM Chip](#) (1)
- [PC2-6400 2 GB RAM Chip](#) (1)
- [PC2-6400 4 GB RAM Chip](#) (1)
- [PC2-5300 512 MB RAM Chip](#) (1)
- [PC2-6400 1 GB RAM Chip](#) (1)

Step 1 — Access Door



- Loosen the single Phillips screw in the center of the access door.
- ⓘ This screw is captive in the access door.
- Remove the access door from your iMac.

Step 2 — RAM



- Use the tip of a spudger to pull the black plastic RAM tabs out of the memory bay.
- Pull the black plastic RAM tab away from your iMac to eject the RAM chip.

Step 3



- Grab the RAM chip by its edges and pull it straight out of its slot.
- ⓘ If two RAM chips are installed, repeat this process for the other chip.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-09 01:54:55 PM.